



POWERED BY CARLSBRO

Carlsbro Holdings Ltd

Unit 11, Torc MK, Chippenham Drive, Milton Keynes,
MK10 0BZ. United Kingdom
Tel: +44(0)1908 281072
Web: www.carlsbro.com Email: sales@carlsbro.com

COLT 30 **keyboard amplifier**

IMPORTANT SAFETY SYMBOLS



- The symbol is used to indicate that some hazardous live terminals are involved within this apparatus, even under the normal operating conditions, which may be sufficient to constitute the risk of electric shock or death.
- The symbol is used in the service documentation to indicate that specific component shall be replaced only by the component specified in that documentation for safety the component specified in that documentation for safety reasons.
- Protective grounding terminal
- Alternating current/voltage
- Hazardous live terminal
- ON: Denotes the apparatus is turned on.
- OFF: Denotes the apparatus is turned off.

WARNING: Describes precautions that should be observed to prevent the danger of injury or death to the operator.

CAUTION: Describes precautions that should be observed to prevent danger of the apparatus.


Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

IMPORTANT SAFETY INSTRUCTIONS

- ☐Read these instructions.
- ☐Keep these instructions.
- ☐Heed all warning.
- ☐Follow all instructions.
- ☐Water & Moisture
- The apparatus should be protected from moisture and rain, can not used near water, for example: near bathtub, kitchen sink or a swimming pool, etc.
- ☐Heat
- The apparatus should be located away from the heat source such as radiators, stoves or other appliances that produce heat.

COLT 30 keyboard amplifier


COLT30 FRONT PANEL



- MIC:**
This socket is for mic input.
- GUITAR:**
This socket is for guitar input.
- KEYBOARD:**
This socket is for keyboard input.
- VOLUME 1:**
This allows adjustment the level of the mic input channel.
- VOLUME 2:**
This allows adjustment the level of the guitar input channel.
- VOLUME 3:**
This allows adjustment the level of the keyboard input channel.
- BASS:**
This control allows the adjustment of the bass frequencies with a cut or boost from the flat position.
- TREBLE:**
This control allows the adjustment of the treble frequencies with a cut or boost from the flat position.
- LINE OUT:**
This is a line-level balanced signal, suitable for connection to a powered mixer, etc.
- PHONES:**
The hones socket provides a mono signal for a stereo headphones set.
- NOTE:** The internal loudspeaker is automatically disconnected when phones are used.
- POWER SWITCH:** This switch turns the mains power to the unit on or off.
NOTE: Always make sure that the volume control is at '0' before turning the unit on or off.

COLT30 REAR PANEL

IEC input socket: Connect the supplied IEC mains lead here. Should the mains fuse need replacing, it is located below the mains input. Replace the fuse only with one of the same type and rating.



NOTE: Always disconnect the unit form the mains supply before changing the fuse.