



**Carlsbro Holdings Ltd**

Unit 11, Torc MK, Chippenham Drive, Milton Keynes,  
MK10 0BZ, United Kingdom  
Tel: +44(0)1908 281072  
Web: [www.carlsbro.com](http://www.carlsbro.com) Email: [sales@carlsbro.com](mailto:sales@carlsbro.com)



**valve amplifier**

## IMPORTANT SAFETY SYMBOLS



The symbol is used to indicate that some hazardous live terminals are involved within this apparatus, even under the normal operating conditions, which may be sufficient to constitute the risk of electric shock or death.



The symbol is used in the service documentation to indicate that specific component shall be replaced only by the component specified in that documentation for safety the component specified in that documentation for safety reasons.



Protective grounding terminal



Alternating current/voltage



Hazardous live terminal

ON: Denotes the apparatus is turned on.

OFF: Denotes the apparatus is turned off.

**WARNING:** Describes precautions that should be observed to prevent the danger of injury or death to the operator.

**CAUTION:** Describes precautions that should be observed to prevent danger of the apparatus.



Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

## IMPORTANT SAFETY INSTRUCTIONS

☐ Read these instructions. ☐ Keep these instructions.

☐ Heed all warning. ☐ Follow all instructions.


### ☐ Water & Moisture

The apparatus should be protected from moisture and rain, can not used near water, for example: near bathtub, kitchen sink or a swimming pool, etc.

### ☐ Heat

The apparatus should be located away from the heat source such as radiators, stoves or other appliances that produce heat.

## EVO 5 FRONT PANEL



### HI / LOW:

This switch is change the gain of the input level between high gain and low gain. Please select a suitable gain for your guitar.

### INPUT:

This socket is for guitar input.

### BASS:

This control allows the adjustment of the bass frequencies with a cut or boost from the flat position.

### TREBLE:

This control allows the adjustment of the treble frequencies with a cut or boost from the flat position.

### VOLUME:

This allows adjustment the level of the guitar input channel.

NOTE: Always make sure that the volume control is at “0” before turning the unit on or off.

### GEM LIGHT:

The light will illuminate when the unit is switched on.

### STANDBY SWITCH:

This switch engages the high voltage DC to the tubes. The unit will be standby when this switch turns off (in the UP position).


## POWER SWITCH:

This switch turns the mains power to the unit on or off.

### NOTE:

Please turn on the Power Switch first, wait for several minutes (at least one minute). Then you can turn on the Standby Switch. It will help the Amp tube operate fitly. If you want to turn the unit off, please turn off the Standby Switch first, then turn off the Power Switch. if you do not intend to use the amplifier for a long period of time, please turn it off to preserve the life of the valves.

## EVO 5 REAR PANEL



## MAINS LEAD:

The lead needs to connect the mains supply with correct voltage.

## AC FUSE:

The fuse is for the AC mains power.

Replace the fuse only with one of the same type and rating.

NOTE: Always disconnect the unit from the mains supply before changing the fuse.